

Removing the DiamondX Mounting Arbor



Method 1

- Secure the wheel face up in a bench vise with the 1" nut of the mounting hub down.
- Use a 1 1/16" offset box wrench to remove the front nut with counter-clockwise turns.



Method 2

- Use a 1" box or socket wrench on the mounting hub nut on the back of the wheel.
- Use a 1 1/16" box or socket wrench on the front nut.
- Secure the wrench on the back nut and remove the front nut with counter-clockwise turns.